

12/02/09



Mailing: P.O. Box 9056, Mesa, AZ 85214-9056  
 Shipping: 7931 E. Pecos Rd.,  
 Bldg. 6, #196, Mesa, AZ 85212  
 Ph: 800-359-9066 Fx: 480-214-0580  
 www.btwest.com / info@btwest.com

<b>QTY</b>	<b>Part Number</b>	<b>Description</b>
<b>2</b>	1028176	CENTRALIZER LINER (PAIR)
<b>6</b>	1028196	PISTON GUIDE ASSEMBLY
<b>9</b>	1028646	ADAPTER STUD
<b>2</b>	1028672	SUPPORT BRACKET ASSEMBLY
<b>1</b>	1028709	ADAPTER
<b>2</b>	1029117	RIFLE BAR
<b>14</b>	1029189	CHUCK DRIVER NUT
<b>17</b>	1029359	BOLT
<b>5</b>	1029843	O RING
<b>4</b>	1029853	FEED SCREW NUT
<b>2</b>	1029868	VALVE CHEST
<b>3</b>	1029885	CHUCK NUT
<b>25</b>	1029886	CHUCK DRIVER NUT S93F
<b>3</b>	1029889	CHUCK DRIVER
<b>6</b>	1029901	FEED LEG BUSHING
<b>2</b>	1029902	BUSHING
<b>3</b>	1029906	WIPER RING (FL630D)
<b>1</b>	1029954	FEED CYLINDER
<b>18</b>	1029959	THROTTLE VALVE
<b>3</b>	1029960	THROTTLE VALVE
<b>12</b>	1031751	PISTON
<b>9</b>	1031758	VALVE PLUG
<b>1</b>	1034145	CHUCK
<b>1</b>	1034172	CHUCK END CAP
<b>1</b>	1034859	MOTOR CYLINDER
<b>1</b>	1035855	BRACKET ASSEMBLY
<b>12</b>	1036272	RATCHET RING (S63F33A35)
<b>5</b>	1036688	HANDLE (FOR S58F18X)
<b>1</b>	1036692	CONTROL HANDLE
<b>13</b>	1036719	WASHER
<b>15</b>	1037232	SWIVEL BUSHING (S93F)
<b>2</b>	1037911	SPACER
<b>43</b>	1037913	BOLT
<b>3</b>	1038305	CAP SCREW
<b>26</b>	1038329	BOLT (BS434)

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
18	1038363	CAP SCREW (SH126)(1DM713)
11	1038373	PISTON ROD
4	1038562	CLAMP
13	1038785	CENTRALIZER LINER (PAIR)
7	1038791	CENTRALIZER LINER (PAIR)
1	1038801	RATCHET RING
12	1038879	RIFLE BAR
72	1039232	CAP SCREW (SH129)
5	10399251	FRONT END CAP
38	10399252	SUPPORT RIBS
10	1040775	CENTRALIZER LINER (PAIR)
2	1040898	FRONTHEAD
1	1041152	MUFFLED CYLINDER
1	104128T15A	CHUCK INSERT
1	10442D2	VALVE
1	1046587	RET RING
2	1048360	LOCK CHECK KIT ASSEMBLY
7	1048398	U CUP (CYL 18H)
4	1048457	BUSHING
1	1049401	WASHER
17	1049957	CAP SCREW
3	1050347	O RING
2	1053383	CAPSCREW
0	1053943	PIN
4	1056026	SUPPORT ASSEMBLY
2	1056826	RETAINING RING
1	1056876	RET RING
2	1058573	SIDE ROD
1	1059054	WATER TUBE
563	10713A	SCREEN
7	10713BA	SEAL
8	10713SA	WATER CONNECTION TUBE
1	1078W	TAPPET
2	12J28	BEARING
2	12J32	BEARING
2	12J33	BUSHING
1	12K102	BEARING
48	14107DG	THROTTLE VALVE BOLT
2	143628	CAP SCREW (1040022)
8	148CX	STREET ELBOW

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
1454	1711A	PAWL
2	1729RE	PLUNGER SPRING
1	17L7CL	SLEEVE BUSHING
1	18295	CLAMP ASSEMBLY
14	1D23275	CHUCK
1	1DH2317A	CHUCK END
27	1DH23602	PLATE C/W O RING
9	1DH23726	SHAFT
32	1DH23786	SPUD
0	1DMCH223	BUSHING
1	1DMCH255	PISTON
1	1DMCP255	CENTRALIZER PISTON ASSEMBLY
23	1FL820	PISTON CUP
1	1PR33115	ADAPTER
1	1PR33277	END CAP
2	1PR33280	CHUCK SLEEVE BUSHING ASSEMBLY
0	1PR55127	TUBE
0	1PR55127B	TUBE REDUCED TO 5/16
0	1PR55278A	BUSHING
3	1R8320A	PLASTIC CUP (R9420PP)
0	1R8320C	PLASTIC CUP
0	1R8320D	PLASTIC CUP (RB9420PA)
6	1R835	PISTON ROD
3	1R83506	WASHER
4	1R835A	PISTON ROD STUD
12	1R835B	PISTON ROD BUSHING
1	1RMEA763	SPACER
0	1S83F715	SEAL
0	1S83F715A	SEAL
1	1S83M1	CYLINDER
8	2111324	BOLT
4	24AV2	NIPPLE
1	2AG16	ROCKER STAND
1	2DPT5	CAP
1	2MEBT6	THROTTLE VALVE
5	33L	BUSHING
35	384N82	SPACER
4	4B4283	WASHER
4	5AF10	ADAPTER SPUD
8	603B	WASHER

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
3	62C40	PIN
0	62C46	PIN (LNP21)
13	62L2	PIN
1	6MC1083	PIN
1	72A	DETENT
0	739A	WASHER
4	75A67	BOLT
27	765DA	STINGER POINT LONG
2	78A310	SPRING (HKE4E)
6	9263	OIL PLUG
4	95G33	WASHER (MB2)
1	A4512F	PIN
1	ACD127C	SEAT
2	ACD506	VALVE
535	AF8982	SPRING
1	AT1044	SHAFT
4	AT1046	CYLINDER PIN BUSHING 1" LONG
2	AT1047	CYLINDER PIN BUSHING 3/4" LONG
1	AT1321X	TRACK LINK
1	AT1344	BUSHING LINK
7	AT1348	PIN
10	AT1431A	KEY
2	AT2471	RETAINING RING
1	AT3392	BUSHING
1	AT503	SPRING
3	B250	THERMAL UNIT
1	B2L236B	PLUG
2	B3715A	COVER
0	B3715C	VALVE
0	B6715	VALVE
0	B6715C	VALVE
0	B6716	PLATE
3	B72716P	CHUCK INSERT
9	B8715C	VALVE CHEST (1B87C15)
3	B8745	BOLT
4	B8747	TUBE ELBOW
1	BB38	BUSHING
1	BFL929D	FEED LEG CAP
20	BS436	BOLT
3	CF73H12E	HANDLE

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
2	CF73H86	HANDLE
9	CF8912E	THROTTLE HANDLE
36	CF892R	DETENT RETAINER
14	CF8946	BUSHING
8	CF8950	VALVE
29	CF8971B	FEED MOTOR RATCHET FRONT
21	CF8980A	RATCHET
3	CF89N12FA	HANDLE
8	CF99146	SPUD
21	CF99147	TUBE
2	CF9947X	3 WAY VALVE
2	CF9962	FEED NUT
1	CF9976FA	RATCHET HALF
1	CJ81B2	BUSHING
5	CM185	HANDLE
30	CME508	SPUD
12	CMF5A	SPUD
2	CYL18E	BACKING PLATE
372	D12311A	PAWL
4	D12311G36	RIFLE BAR
1	D7312E	THROTTLE HANDLE
3	D7316	AUTOMATIC VALVE
11	D731W	WASHER
0	D73H146	SWIVEL AIR CONNECTION NUT
22	D73H149	RETAINER RING
3	D73H149	RETAINER RING
2	D798WL	TAPPET
2	D799A	PISTON
1	D8329D	DRY GLAND (1039146)
1	D8329W	BACKHEAD GLAND (1039134)
3	D8340	WASHER
0	D83N40	WATER GLAND ASSEMBLY
0	D83N45	VALVE SEAT
1	D89125	SPRING
1	D8912E	THROTTLE HANDLE
1	D8913C	SWIVEL SPUD
11	D8913D	SWIVEL SPUD
1	D89146	SPUD
9	D89147	AIR CONNECTION NUT
4	D897BN	CHUCK NUT

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
6	D897CL	CHUCK SLEEVE BUSHING
1	D89B9A	PISTON
2	D931038	RIFLE NUT
3	D931138	RIFLE BAR
6	D9312E	HANDLES
3	D93146	SPUD
1	D9315B	VALVE PLUG
2	D9317	CHUCK END
24	D933	SIDE ROD
2	D937L	CHUCK DRIVER
1	D937LA	CHUCK DRIVER
11	D937W	LOCK WIRE
35	D93AR27J	WATER TUBE 5/16"
1	D93AR59	CAP
2	D93AR69	BEARING PLATE ASSEMBLY
1	D93AR7T64	CHUCK LINER 1" HEX
1	D93AR7T6H	CHUCK LINER 1" (1041273)
1	D93J49	RETAINER RING
1	D9915	VALVE CHEST
5	D9927G	WATER & AIR TUBE
1	D997BL	CHUCK
1	D997F	CHUCK
2	D997FB	CHUCK
6	D997N	CHUCK NUT
3	D999AA	PISTON
0	DH12310A36	RIFLE NUT
3650	DH12311C	SPRING
3	DH12311E36	RIFLE BAR
18	DH12312A	THROTTLE VALVE
40	DH12317J	CHUCK END CAP (1.760)
3	DH1232	BACKHEAD (MANUAL)
18	DH12327G	WATER TUBE
1	DH1232X	BACKHEAD ASSEMBLY (MANUAL)
8	DH1237HR	CHUCK
1	DH1237NC	CHUCK DRIVER NUT
17	DH123P	PLUG
2	DH143	CHUCK NUT
1	DH143135	ROTATION SHAFT
87	DH143150	LOCK SPRING
4	DH9912E	HANDLE

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
<b>40</b>	DH99134	PAWL LIFTER
<b>17</b>	DH99135	ROTATION CONTROL SHAFT
<b>113</b>	DH992R	DETENT RETAINER
<b>4</b>	DH997L	CHUCK
<b>1</b>	DM303C	WASHER
<b>1</b>	DM427A	SPRING
<b>0</b>	DM433B	CENTRALIZER LINER (PAIR)
<b>2</b>	DM435	CENTRALIZER BUSHING
<b>0</b>	DM438	CENTRALIZER LOCK BOLT
<b>0</b>	DM439	CENTRALIZER SPRING
<b>0</b>	DM504C	BOLT
<b>4</b>	DMC435	BUSHING
<b>6</b>	DMC755	SPRING
<b>5</b>	DMC784	DETENT
<b>10</b>	DMC786	BUSHING
<b>1</b>	DMC793	ARM
<b>1</b>	DMC824	BRACKET
<b>12</b>	DMC847	CENTRALIZER LOCK BOLT
<b>3</b>	DMC847X	CENTRALIZER LOCK BOLT ASSEMBLY
<b>57</b>	DMC851P	BUSHING
<b>1</b>	DMC853RB	CENTRALIZER ARM ASSEMBLY
<b>3</b>	DMC854LB	CENTRALIZER ARM ASSEMBLY
<b>8</b>	DMC855RB	CENTRALIZER ARM ASSEMBLY
<b>9</b>	DMC856LB	CENTRALIZER ARM ASSEMBLY
<b>5</b>	DPT12A	BUSHING
<b>4</b>	DPT4	CLEVIS ASSEMBLY
<b>0</b>	ERP13	PIN
<b>10</b>	ERP18	PIN
<b>10</b>	ERP6	PIN
<b>23</b>	FL1027R	RING
<b>4</b>	FL1029	BASE CAP
<b>1</b>	FL1043	HANDLE
<b>18</b>	FL1227	BASE CAP
<b>11</b>	FL1286	SPACER
<b>2</b>	FL1287	SLEEVE
<b>0</b>	FL319	SLEEVE
<b>0</b>	FL331A	FEED CYLINDER BUSHING
<b>0</b>	FL3B11	FEED CONTROL VALVE
<b>0</b>	FL3B12	END UNIT PLUG BUSHING
<b>0</b>	FL3B13	FEED CONTROL VALVE SPRING

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
0	FL3B15	CONTROL VALVE
0	FL3B16	CONTROL VALVE ADJUSTING SCREW
191	FL520	PISTON CUP
8	FL527	FEED CYLINDER REAR CAP
7	FL528B	PISTON SLEEVE
7	FL530B	CUP LEATHER KEEPER
3	FL543	HOLDING HANDLE
15	FL590A	SWIVEL
1	FL591	PIVOT STUD
0	FL594	PIVOT CONE
0	FL595	PIVOT CONE SPLINED
0	FL599	NUT
12	FL5A29	FEED CYLINDER CAP
9	FL5A36	CUP LEATHER SPACER
3	FL627	CAP
7	FL643	HANDLE (1FL6468)
1	FL7200	PIN
1	FL7202	NUT
0	FL721	NUT ASSEMBLY
7	FL7210A	CYLINDER BUSHING (1045660)
28	FL7211	RETAINER RING
1	FL727A	CYLINDER CAP
1	FL729	
1	FL731	CYLINDER BUSHING
3	FL8203A	CYLINDER BUSHING
4	FL820PA	COMPRESSION CUP (1FL820)
1	FL827	HEAD CAP
4	FL829	HEAD CAP
1	FL831	CYLINDER BUSHING
3	FL938	PISTON HEAD
12	FL986	KEEPER
9	FL987	PISTON HEAD (1FL924)
5	H8118R	SPRING RETAINER
3140	H8118S	SPRING
4	H8118T	PLUG
8	HBD13A	PINION GEAR
1	HBD13A	PINION GEAR
1	HBD39	BRACKET
2	HEE702	VALVE BUSHING
4	HKE21	PIN



<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
1	HKE3DAL	BRAKE LEVER
1	HKE56	VALVE HANDLE
1	HKJ1A	VALVE CHEST
4	K10	KEY
21	K13H	WOODRUFF KEY
14	K3	KEY
30	K5	KEY
4	L11	RETAINER
6	LNP21	PIN (62C46)
9	LO76A	FILLER PLUG
4	LO76AX	LUBE PLUG C/W LEATHER WASHER
1	LO77	SPRING
1	LO78AX	NOZZLE ASSEMBLY
37	LO79	LEATHER WASHER
2	M151042	THROTTLE VALVE
5	MA222	CAP
23	MA223	GASKET
1	MA23D51	ADAPTOR
8	MA2MC40A	GEAR SHAFT
0	MA2MS113P	SUPPORT
2	MA2MS412	CLAMP
2	MA2MS85	HOUSING
5	MA2MS86A	VALVE
2	MA2MS87	LEVER
11	MA2MS88	RATCHET
14	MA2MS89	SLEEVE
4	MA2MSU113	VALVE
2	MA2MSU116	PLATE
8	MA2MSU213	HOUSING
3	MA2MSU44	IDLER GEAR
38	MA2MSU87	HANDLE
1	MA2MSU92A	HOUSING
1	MA319	GASKET
1	MA326B	CONNECTING ROD
2	MA326WA	WASHER
4	MA327	CONNECTING ROD
2	MA328C	CRANK
1	MA330D	CRANK
1	MA342	BREATHER CAP
1	MA3A1A	VALVE CHEST

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
1	MA3A3	SHAFT
1	MA3GS6	KEY
6	MB25	PIN
0	MB30X	MOTOR CRANKSHAFT ASSEMBLY
1	MB56	THROTTLE HANDLE
1	MBG40A	DRIVE GEAR
20	MERM36	GASKET
2	MK10	WASHER
3	MK13B	THROTTLE VALVE
55	MK21	DOWEL PIN (DP162)
3	MK25	PISTON PIN
4	MK28	BUSHING
1	MK30Y	CRANKSHAFT DRIVE END
1	MK33	BUSHING
3	MK4	PIN
1	MK8A	THROTTLE VALVE CAP
4	MM25	PISTON PIN
2	MMGC63	DETENT
1	NB15	NUT
15	NC66	NUT SLOTTED
6	NH10	NUT
0	NH108	NUT
1	NH17	NUT (143721)
16	NH20	NUT (143722)
65	NH22	NUT (123074)
102	NZ163	NUT
2	OB59	DETENT
0	OR24	O RING
0	OR3	O RING
0	OR5	O RING
2	ORP214B	O RING
1	ORP344B	"O" RING
12	ORP344B	"O" RING
50	ORS28	O RING
0	OS3	OIL SEAL (60G115)
5	OS39	OIL SEAL
2	OS50	OIL SEAL
54	OS60	OIL SEAL
6	OS82	SEAL
126	PM5	PIN

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
4	PM6	CENTRALIZER BUSHING
40	PP1A	ALLEN PIPE PLUG
0	PP2A	ALLEN PIPE PLUG
1	PP2S	PLUG
4	PP3A	PLUG
5	PP4	PLUG
1	PP5A	PLUG
2	PP7A	PLUG
1	PR133J27P	TUBE
7	PR133J3	SIDE ROD
13	PR133J3D	SPACER
2	PR14327P	BLOW TUBE (PLASTIC)
1	PS17	STREET ELBOW
1	PS6	ELBOW
12	PS9	STREET ELBOW (120081)
15	PSQ16	STREET ELBOW
130	R10411A	PAWL
342	R10411CB	PAWL SPRING (S93F78C2)
13	R10418C	VALVE RETAINER
187	R10418D	BUTTON STOP
580	R10418E	BUTTON SPRING
183	R10418FA	SPRING
78	R10418G	BUTTON RETAINER
2	R10418K	STOPER HANDLE COMPLETE
31	R10418RA	VALVE SLEEVE (RB8318J)
279	R10418W	BUTTON RETAINER WASHER
32	R10421	NUT
66	R10421W	WASHER
57	R10422	CLUTCH RING
17	R10426	GUIDE WASHER
59	R1044BA	TAPPET
4	R1044NA	FEED PISTON GUIDE WASHER
24	R11120LV	COMPRESSION CUP
10	R911035	RIFLE NUT
3	R941135	RIFLE BAR
1	R9412E	THROTTLE VALVE HANDLE
8	R9420A	PISTON CUP
1	R9424A	KEEPER
3	R947NA	CHUCK NUT
6	R948	TAPPET

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
2	R94K589	PISTON
1	RB10412E	THROTTLE VALVE HANDLE
97	RB10418D	DETENT
1	RB10418P	CONTROL VALVE
272	RB10418S	SPRING
1	RB1042A	BACKHEAD
10	RB5333C	CONTROL HANDLE
48	RB83146	AIR CONNECTION NUT
6	RB8319A	YOKE
17	RB8319D	YOKE
14	RB8319W	YOKE
3	RB8324	KEEPER
5	RB8325	KEEPER
62	RB8327TW	WATER TUBE
0	RB8327W	WATER TUBE
0	RB834K	BUSHING C/W ROLL PIN
0	RB834T	BUSHING
42	RB837D	CHUCK DRIVER
8	RB83V18N	HOLDING HANDLE NUT
11	RB941038	RIFLE NUT
18	RF5G	AIR CONNECTION
4	RMB185A	CHAIN FORK
1	RME10185	CHAIN FORK
1	RMEH1063AS	BRACKET (1RMEH212)
7	RMEH1067F	BOLT (1053381)
15	RMH10593	SPACER
9	RMH10596	BLOCK
8	RW18	BEARING
5	RW4	BEARING
2	S332628	RIFLE BAR
10	S3536R	RING
11	S4533P	VALVE CHEST PIN
0	S4813D	SPUD
4	S4815C	VALVE PLUG
1	S4817TA	FRONT END
4	S481C	SEAL (1S48715)
5	S482628	RIFLE BAR
1	S483335	RATCHET RING
6	S4836EA	SPRING
1	S4836F	SPRING RETAINER

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
23	S4836G	LOCK RING
9	S483W	WASHER (R683W)
47	S488A	TAPPET
2	S488BA	TAPPET SPLINED
3	S48F12AA	THROTTLE VALVE
1	S48F12N	NUT
5	S48F147C	AIR CONNECTION SWIVEL
18	S48F147S	AIR CONNECTION TUBE ASSEMBLY
7	S48F147SA	TUBE C/W D73H146 NUT
6	S48F150	VALVE RATCHET SPRING
1	S48F17FB	FRONT HEAD
5	S48F23	SPRING RETAINER
3	S48F2AX	BACKHEAD ASSEMBLY
3	S48F34D	HANDLE
6	S48F36	STEEL PULLER
1	S48F36B	STEEL PULLER
2	S48F37	BUSHING
0	S48F7D	CHUCK DRIVER
1	S48R821	PISTON
16	S53F1BA	INTERMEDIATE PART
1	S53F25C	VALVE
2	S53F9A	PISTON
8	S5512CX	BOLT ASSEMBLY
10	S553C	SIDE ROD
202	S557LLB	CHUCK LINER (1041286)
1	S580779	PISTON
1	S5817CB	FRONT END
36	S582628	RIFLE BAR
0	S5827D	TUBE
3	S5827G	WATER TUBE
2	S5827WC	WATER TUBE
9	S5835W	WASHER
2	S5836A	STEEL PULLER
3	S587113	PIN
54	S587N	CHUCK DRIVER NUT
21	S58F12DA	THROTTLE VALVE
0	S58F15B	PLUG
3	S58F17C	FRONTHEAD
3	S58F17TB	FRONTHEAD
9	S58F18C	HOLDING HANDLE (1036692)

<b>QTY</b>	<b>Part Number</b>	<b>Description</b>
<b>14</b>	S58F18K	HOLDING HANDLE (1S58F468-10367)
<b>4</b>	S58F18KX	HOLDING HANDLE ASSY (1045633)
<b>2</b>	S58F20	PISTON CUP
<b>1</b>	S58F2A	BACKHEAD
<b>0</b>	S58F2D	BACKHEAD
<b>0</b>	S58F2TB	SLEEVE
<b>11</b>	S58F36A	STEEL PULLER
<b>0</b>	S58F36K	PIN (1053943)
<b>0</b>	S58F36N	SPRING
<b>33</b>	S58F36RA	RETAINER ASSY (1055692) (1053971)
<b>5</b>	S58F4E	WASHER
<b>7</b>	S58F7D	CHUCK DRIVER
<b>13</b>	S58F7H	CHUCK
<b>2</b>	S58F7J	CHUCK
<b>48</b>	S58F7R	CHUCK
<b>1</b>	S58F7TF	CHUCK LINER (1041290)
<b>9</b>	S58F7TH	CHUCK LINER
<b>0</b>	S58F7TLF	CHUCK LINER ( <b>ADD TO WGD 1041285</b> )
<b>11</b>	S63F120	RETAINER
<b>8</b>	S63F122	USE 1S83F715A
<b>15</b>	S63F15	VALVE CHEST
<b>3</b>	S63F15P	VALVE PLUG
<b>3</b>	S63F15X	VALVE CHEST
<b>9</b>	S63F1BA	CYLINDER BUSHING ASSEMBLY
<b>3</b>	S63F27B	WATER TUBE (S5827WC)
<b>1</b>	S63F27W	WATER TUBE
<b>8</b>	S63F3	SIDE ROD
<b>36</b>	S83F100	BLOWER PORT CONNECTION
<b>9</b>	S83F101	SPRING
<b>2</b>	S83F114	D HANDLE ASSEMBLY
<b>0</b>	S83F117	SPRING
<b>0</b>	S83F12	THROTTLE VALVE
<b>0</b>	S83F120	RETAINER
<b>0</b>	S83F15D	VALVE CHEST PIN
<b>0</b>	S83F3	SIDE ROD
<b>3</b>	S93F1C	CYLINDER
<b>24</b>	S93F1L	CYLINDER BUSHING
<b>66</b>	S93F27D	AIR TUBE
<b>2</b>	S93F3GX	SIDE ROD ASSEMBLY
<b>4</b>	S93F7D	DRIVER

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
1	SF102A	HOSE CONNECTION
2	SF17	SPACER
1	SF2	FEED MOTOR FRONT HOUSING
14	SF2P	DETENT RETAINING PIN
1	SF4	GEAR RACK
8	SF41	SCREEN
5	SF41R	SCREEN RETAINER
1	SF42L	HOUSING
6	SF44A	PLATE
4	SF62	FEED SCREW NUT
5	SF68	DRIVE PISTON
3	SF69A	RATCHET CAGE
1	SF7	SPUD
5	SF76	FEED PAWL CONTROL
23	SF78B	SHAFT
9	SF78BA	SHAFT
1	SF8	PLUG
11	SF81	CAM
2	SF82	SPRING
5	SF86B	THROTTLE VALVE
4	SF86KB	KEY
12	SF86N	NUT
19	SF87	FEED CONTROL PACKING
6	SF96	NUT
2	SF97	AIR CONNECTION TUBE
11	SF99D	BOLT
6	SFH137	PIN
41	SFH138	IDLER GEAR
2	SFH140A	WEAR PLATE
2	SFH140PA	WEAR PLATE
8	SFH142P	NYLON PIN
3	SFH143	COVER PLATE
1	SFH145	COVER PLATE
1	SFH17	SPACER
2	SFH245	FEED PLATE
43	SFH246	WEAR PLATE
22	SFH247	GEAR
24	SFH39	GEAR
3	SFH50	SUPPORT
9	SFH83A	FEED CONTROL VALVE

<b>QTY IN STK</b>	<b>Part Number</b>	<b>Description</b>
2	SFH99	BOLT
1	SH140	BOLT
1	SH158	BOLT
42	SH168	CAP SCREW (127242)
20	SH64	CAP SCREW (105150)
7	SHA24	SCREW
10	SHA5	CAPSCREW
2	SHC17R	AIR CONNECTION NIPPLE
4	SHC98	SPUD
21	SP15	SET SCREW
1	SP27150	COVER
1	SP58585	PLATE
1	SP8	PLUG
0	TFL629H	RETAINER
0	TFL630A	CYLINDER CAP ASSEMBLY
0	TFL631	CYLINDER BUSHING
8	TFL640A	CUP LEATHER
18	TFL640P	PISTON CUP (1TFL620C)
0	TFL643	HANDLE (1TFL6468)
0	TFL686	PISTON CUP SPACER (1TFL6506)
0	TFL687	PISTON SLEEVE (1TFL6124)
45	TRR30	RETAINING RING
8	TRR33	RETAINING RING
0	TRR5	RETAINING RING
0	TRR7	RETAINING RING (65W23)
13	UCP1	U CUP PACKING
27	W14	WASHER
40	WP11	LOCK WASHER (121071)
4	WP12	WASHER
38	WP14	LOCK WASHER
25	WP17	WAHER
11	WP33	LOCK WASHER
6	WP33	LOCK WASHER
6	WP7	WASHER LOCK
21	WS36	WASHER